

## Android devices for which operation has been confirmed

Brand	Device Name	Model Number	OS
Google	Nexus 5X	-	8.1
Google	Nexus 6P	-	8.1
Google	Pixel	-	9.0
Google	Pixel XL	-	8.0
Google	Pixel 2	-	8.1
Google	Pixel 2 XL	-	9.0
Google	Pixel 3	-	9.0
Google	Pixel 3 XL	-	9.0
Google	Pixel 3a	-	9.0
Google	Pixel 3a XL	-	9.0
Google	Pixel 4	-	10.0
Google	Pixel C	-	8.1
Samsung	Galaxy S6 Edge	SCV31	7.0
Samsung	Galaxy S6 Edge Plus	SM-G928A	7.0
Samsung	Galaxy S6 Active	SM-G890A	7.0
Samsung	Galaxy S7	SM-G930F	7.0
Samsung	Galaxy S7	SM-G930U	7.0
Samsung	Galaxy S7 Edge	SC-02H	8.0
Samsung	Galaxy S7 Edge	SM-G935FD	7.0
Samsung	Galaxy S7 Active	SM-G891A	7.0
Samsung	Galaxy S8	SM-G9500	7.0
Samsung	Galaxy S8	SM-G950FD	8.0
Samsung	Galaxy S8 Plus	SM-G9550	8.0
Samsung	Galaxy S8 Plus	SM-G955FD	7.0
Samsung	Galaxy S9	SM-G960U1	8.0
Samsung	Galaxy S9 Plus	SM-G965U1	9.0
Samsung	Galaxy S10	SM-G9730	9.0
Samsung	Galaxy S10e	SM-G970F	9.0
Samsung	Galaxy Tab S2 8.0	SM-T713	7.0
Samsung	Galaxy Tab S2 8.0	SM-T710	7.0
Samsung	Galaxy Tab S2 9.7	SM-T813	7.0
Samsung	Galaxy Tab S2 9.7	SM-T810	7.0
Samsung	Galaxy Tab S3	SM-T820	7.0
Samsung	Galaxy Tab S4	SM-T830	8.1
Samsung	Galaxy Tab S5e	SM-T720	9.0
Samsung	Galaxy Tab S6	SM-T860	9.0

These are the results of operational checks performed by Yamaha Corporation, and do not constitute a guarantee of operation. Yamaha Corporation assumes no responsibility for damages arising through use of this application. Your understanding on this matter is appreciated.