


# YAMAHA

## ML80 TONE GENERATOR ボイス リスト



### 目次

XG Voice List (ノーマルボイス)	1 ~ 16
TG300-B Voice List (ノーマルボイス)	17 ~ 24
C/M Voice List (ノーマルボイス)	25
Performance List (パフォーマンス)	26
XG Drum Map (ドラムボイス)	27
TG300-B Drum Map (ドラムボイス)	28
C/M Drum Map (ドラムボイス)	29

# XG Voice List (ノーマルボイス)

Bank Select MSB=000, LSB= バンクナンバー

Instrument Group	Pgm #	KSP		Stereo		Single		Slow		Fast Decay			
		Bank 0	EL	Bank 1	EL	Bank 3	EL	Bank 6	EL	Bank 8	EL	Bank 12	EL
Piano	1	GrandPno	1	GrndPnoK	1								
	2	BritePno	1	BritPnoK	1								
	3	E.Grand	2	EIGrPnoK	2								
	4	HnkyTonk	2	HnkyTnkK	2								
	5	E.Piano1	2	EI.Pno1K	1								
	6	E.Piano2	2	EI.Pno2K	1								
	7	Harpsi.	1	Harpsi.K	1								
	8	Clavi.	2	Clavi. K	1								
Chromatic Percussion	9	Celesta	1										
	10	Glocken	1										
	11	MusicBox	2										
	12	Vibes	1	VibesK	1								
	13	Marimba	1	MarimbaK	1								
	14	Xylophon	1										
	15	TubulBel	1										
	16	Dulcimer	1										
Organ	17	DrawOrgn	1										
	18	PercOrgn	1										
	19	RockOrgn	2										
	20	ChrchOrg	2										
	21	ReedOrgn	1										
	22	Acordion	2										
	23	Harmnica	1										
	24	TangoAcid	2										
Guitar	25	NylonGtr	1										
	26	SteelGtr	1										
	27	Jazz Gtr	1										
	28	CleanGtr	1										
	29	Mute.Gtr	1										
	30	Ovrdrive	1										
	31	Dist.Gtr	1									DstRthmG	2
	32	GtrHarmo	1										
Bass	33	Aco.Bass	1										
	34	FngrBass	1										
	35	PickBass	1										
	36	Fretless	1										
	37	SlapBas1	1										
	38	SlapBas2	1										
	39	SynBass1	1										
	40	SynBass2	2					MelloSB1	1			Seq Bass	2
Strings	41	Violin	1						SlowVln	1			
	42	Viola	1										
	43	Cello	1										
	44	Contrabs	1										
	45	Trem.Str	1						SlowTrStr	1			
	46	Pizz.Str	1										
	47	Harp	1										
	48	Timpani	1										
Ensemble	49	Strings1	1			S.Strngs	2		SlowStr	1			
	50	Strings2	1			S.SlwStr	2		LegatoSt	2			
	51	Syn.Str1	2										
	52	Syn.Str2	2										
	53	ChoirAah	1			S.Choir	2						
	54	VoiceOoh	1										
	55	SynVoice	1										
	56	Orch.Hit	2										
Brass	57	Trumpet	1										
	58	Trombone	1										
	59	Tuba	1										
	60	Mute.Trp	1										
	61	Fr.Horn	1					FrHrSolo	2				
	62	BrasSect	1										
	63	SynBras1	2									QuackBr	2
	64	SynBras2	1										

↓ 9ページへ続く... ↓

Bank 0と同じ音色が入っています。

Double Attack		Bright		Dark		Rsonant		Attack					
Bank 14	EL	Bank 16	EL	Bank 17	EL	Bank 18	EL	Bank 19	EL	Bank 20	EL	Bank 24	EL
						MelloGrP	1						
						MelloEP1	2						
												70sPcOr1	2
		NylonGt2	1										
		SteelGt2	1										
						MelloGr	1						
												DistGtr2	2
						FingrDrk	2						
						SynBa1Dk	1			FastResB	1	AcidBass	1
						ClkSynBa	2	SynBa2Dk	1				
												ArcoStr	2
		Ch.Aahs2	2										
		Trumpet2	1	BriteTrp	2								
						Trmbone2	2						
		Tuba 2	1										
SfrzndBr	2												
										RezSynBr	2	PolyBrss	2
						Soft Brs	2						

↓ 10ページへ続く... ↓

# XG Voice List (ノーマルボイス)

## Bank Select MSB=000, LSB= バンクナンバー

Instrument Groupe	Pgm #	Bank 0		Release		Rezo Sweep		Muted		Detune 1		Detune 2	
		Bank 0	EL	Bank 25	EL	Bank 27	EL	Bank 28	EL	Bank 32	EL	Bank 33	EL
Piano	1	GrandPno	1										
	2	BritePno	1										
	3	E.Grand	2							Det.CP80	2		
	4	HnkyTonk	2										
	5	E.Piano1	2							Chor.EP1	2		
	6	E.Piano2	2							Chor.EP2	2	DX Hard	2
	7	Harpsi.	1	Harpsi.2	2								
	8	Clavi.	2				ClaviWah	2					
Chromatic Percussion	9	Celesta	1										
	10	Glocken	1										
	11	MusicBox	2										
	12	Vibes	1										
	13	Marimba	1										
	14	Xylophon	1										
	15	TubulBel	1										
	16	Dulcimer	1										
Organ	17	DrawOrgn	1							DetDrwOr	2	60sDrOr1	2
	18	PercOrgn	1							DetPrcOr	2	LiteOrg	2
	19	RockOrgn	2										
	20	ChrchOrg	2							ChurOrg3	2		
	21	ReedOrgn	1										
	22	Acordion	2							AccordIt	2		
	23	Harmnica	1							Harmo 2	2		
	24	TangoAcd	2										
Guitar	25	NylonGtr	1	NylonGt3	2								
	26	SteelGtr	1										
	27	Jazz Gtr	1							JazzAmp	2		
	28	CleanGtr	1							ChorusGt	2		
	29	Mute.Gtr	1										
	30	Ovrdrive	1										
	31	Dist.Gtr	1										
	32	GtrHarmo	1										
Bass	33	Aco.Bass	1										
	34	FngrBass	1			FlangeBa	2						
	35	PickBass	1					MutePkBa	1				
	36	Fretless	1							Fretles2	2	Fretles3	2
	37	SlapBas1	1			ResoSlap	1			PunchThm	2		
	38	SlapBas2	1										
	39	SynBass1	1										
	40	SynBass2	2							SmthBa 2	2		
Strings	41	Violin	1										
	42	Viola	1										
	43	Cello	1										
	44	Contrabs	1										
	45	Trem.Str	1										
	46	Pizz.Str	1										
	47	Harp	1										
	48	Timpani	1										
Ensemble	49	Strings1	1										
	50	Strings2	1										
	51	Syn.Str1	2			ResoStr	2						
	52	Syn.Str2	2										
	53	ChoirAah	1							MelChoir	2		
	54	VoiceOoh	1										
	55	SynVoice	1										
	56	Orch.Hit	2										
Brass	57	Trumpet	1							WarmTrp	2		
	58	Trombone	1										
	59	Tuba	1										
	60	Mute.Trp	1										
	61	Fr.Horn	1							FrHorn2	1		
	62	BrasSect	1										
	63	SynBras1	2			SynBras3	2			JumpBrss	2		
	64	SynBras2	1										

↓ 11ページへ続く... ↓

Bank 0と同じ音色が入っています。

Bank 34	EL	Bank 35	EL	Bank 36	EL	Bank 37	EL	Bank 38	EL	Bank 39	EL	Bank 40	EL
												PianoStr	2
												EIGrPno1	2
												HardEL.P	2
DXLegend	2											DX Phase	2
		Harpsi.3	2										
		Dulcimr2	2										
60sDrOr2	2	70sDrOr1	2	DrawOrg2	2	60sDrOr3	2	EvenBar	2			16+2*2/3	2
						PercOrg2	2						
		ChurOrg2	2									NotreDam Puff Org	2
		12StrGtr	2									Nyln&Stl	2
												FunkGtr1	2
		DistGtr3	2	PowerGt2	2	PowerGt1	2	Dst.5ths	2			FeedbkGt	2
												JazzRthm	2
												Ba&DstEG	2
Fretles4	2												
		Clv Bass	2									TeknoBa ModulrBa	2
												Susp Str	2
												YangChin	2
		60sStrng	2									Orchestr Warm Str	2
		Syn Str 3	2										
												ChoirStr	2
												SynVox2	2
		OrchHit2	2										
						HornOrch	2						
		Tp&TbSec	2							BrssFall	1	BrssSec2	2
												SynBrss4	2

↓ 12ページへ続く... ↓

# XG Voice List (ノーマルボイス)

Bank Select MSB=000, LSB= バンクナンバー

Instrument Groupe	Pgm #	Bank 0		Bank 41		Bank 42		Bank 43		Bank 45		Bank 64	
		EL		EL		EL		EL		EL		EL	
Piano	1	GrandPno	1	Dream	2								
	2	BritePno	1										
	3	E.Grand	2	EIGrPno2	2								
	4	HnkyTonk	2										
	5	E.Piano1	2							VX EI.P1	2	60sEI.P	1
	6	E.Piano2	2	DX+Analg	2	DXKotoEP	2			VX EI.P2	2		
	7	Harpsi.	1										
	8	Clavi.	2										PulseClv
Chromatic Percussion	9	Celesta	1										
	10	Glocken	1										
	11	MusicBox	2									Orgel	2
	12	Vibes	1							HardVibe	2		
	13	Marimba	1									SineMrb	2
	14	Xylophon	1										
	15	TubulBel	1										
	16	Dulcimer	1										
Organ	17	DrawOrgn	1									Organ Ba	1
	18	PercOrgn	1										
	19	RockOrgn	2									RotaryOr	2
	20	ChrchOrg	2									OrgFlute	2
	21	ReedOrgn	1										
	22	Acordion	2										
	23	Harmnica	1										
	24	TangoAcd	2									TngoAcd2	2
Guitar	25	NylonGtr	1					VelGtHrm	2				
	26	SteelGtr	1	Stl&Body	2								
	27	Jazz Gtr	1										
	28	CleanGtr	1									CleanGt2	1
	29	Mute.Gtr	1	MuteStlG	2			FunkGtr2	2	Jazz Man	1		
	30	Ovrdrive	1					Gt.Pinch	2				
	31	Dist.Gtr	1	FeedbGt2	2			RkRythm2	2	RockRthm	2		
	32	GtrHarmo	1									AcoHarmo	1
Bass	33	Aco.Bass	1							VXUprght	2		
	34	FngrBass	1					FngrSlap	2	FngBass2	2	JazzBass	1
	35	PickBass	1										
	36	Fretless	1										
	37	SlapBas1	1										
	38	SlapBas2	1					VeloSlap	2				
	39	SynBass1	1									Oscar	2
	40	SynBass2	2	DX Bass	2							X WireBa	2
Strings	41	Violin	1										
	42	Viola	1										
	43	Cello	1										
	44	Contrabs	1										
	45	Trem.Str	1										
	46	Pizz.Str	1										
	47	Harp	1										
	48	Timpani	1										
Ensemble	49	Strings1	1	Orchstr2	2	TremOrch	2			VeloStr	2		
	50	Strings2	1	Kingdom	2							70s Str	1
	51	Syn.Str1	2									Syn Str4	2
	52	Syn.Str2	2										
	53	ChoirAah	1									StrngAah	1
	54	VoiceOoh	1									VoiceDoo	1
	55	SynVoice	1	Choral	2							AnaVoice	1
	56	Orch.Hit	2									Impact	2
Brass	57	Trumpet	1										
	58	Trombone	1										
	59	Tuba	1										
	60	Mute.Trp	1									MuteTrp2	1
	61	Fr.Horn	1										
	62	BrasSect	1	HiBrass	2	MelloBrs	2						
	63	SynBras1	2							AnaVelBr	2	AnaBrss1	2
	64	SynBras2	1	ChoirBrs	2					VelBrss2	2	AnaBrss2	2

↓ 13ページへ続く... ↓

Bank 0と同じ音色が入っています。



# XG Voice List (ノーマルボイス)

Bank Select MSB=000, LSB= バンクナンバー

Instrument Groupe	Pgm #	Bank 0	EL	Bank 72	EL	Bank 96	EL	Bank 97	EL	Bank 98	EL	Bank 99	EL
Piano	1	GrandPno	1										
	2	BritePno	1										
	3	E.Grand	2										
	4	HnkyTonk	2										
	5	E.Piano1	2										
	6	E.Piano2	2										
	7	Harpsi.	1										
	8	Clavi.	2										
Chromatic Percussion	9	Celesta	1										
	10	Glocken	1										
	11	MusicBox	2										
	12	Vibes	1										
	13	Marimba	1			Balafon	2	Balafon2	2	Log Drum	2		
	14	Xylophon	1										
	15	TubulBel	1			ChrchBel	2	Carillon	2				
	16	Dulcimer	1			Cimbalom	2	Santur	2				
Organ	17	DrawOrgn	1										
	18	PercOrgn	1										
	19	RockOrgn	2										
	20	ChrchOrg	2										
	21	ReedOrgn	1										
	22	Acordion	2										
	23	Harmnica	1										
	24	TangoAcd	2										
Guitar	25	NylonGtr	1			Ukulele	1						
	26	SteelGtr	1			Mandolin	2						
	27	Jazz Gtr	1			PdlSteel	1						
	28	CleanGtr	1										
	29	Mute.Gtr	1			Mu.DstGt	2						
	30	Ovrdrive	1										
	31	Dist.Gtr	1										
	32	GtrHarmo	1										
Bass	33	Aco.Bass	1										
	34	FngrBass	1										
	35	PickBass	1										
	36	Fretless	1			SynFretl	2	Smooth	2				
	37	SlapBas1	1										
	38	SlapBas2	1										
	39	SynBass1	1			Hammer	2						
	40	SynBass2	2										
Strings	41	Violin	1										
	42	Viola	1										
	43	Cello	1										
	44	Contrabs	1										
	45	Trem.Str	1										
	46	Pizz.Str	1										
	47	Harp	1										
	48	Timpani	1										
Ensemble	49	Strings1	1										
	50	Strings2	1										
	51	Syn.Str1	2										
	52	Syn.Str2	2										
	53	ChoirAah	1										
	54	VoiceOoh	1			VoiceHmn	1						
	55	SynVoice	1										
	56	Orch.Hit	2										
Brass	57	Trumpet	1			FluglHrn	1						
	58	Trombone	1										
	59	Tuba	1										
	60	Mute.Trp	1										
	61	Fr.Horn	1										
	62	BrasSect	1										
	63	SynBras1	2										
	64	SynBras2	1										

↓ 15ページへ続く... ↓

Bank 0と同じ音色が入っています。





# XG Voice List (ノーマルボイス)

Bank Select MSB=000, LSB= バンクナンバー  
KSP Stereo Single Slow Fast Decay

Instrument Group	Pgm #	Bank 0	EL	Bank 1	EL	Bank 3	EL	Bank 6	EL	Bank 8	EL	Bank 12	EL
↓ 1ページ続き... ↓													
Reed	65	SprnoSax	1										
	66	Alto Sax	1										
	67	TenorSax	1										
	68	Bari.Sax	1										
	69	Oboe	2										
	70	Eng.Horn	1										
	71	Bassoon	1										
	72	Clarinet	1										
Pipe	73	Piccolo	1										
	74	Flute	1										
	75	Recorder	1										
	76	PanFlute	1										
	77	Bottle	2										
	78	Shakhchi	2										
	79	Whistle	1										
	80	Ocarina	1										
Synth Lead	81	SquareLd	2					Square 2	1	LMSquare	2		
	82	Saw.Lead	2					Saw 2	1	ThickSaw	2		
	83	CaliopLd	2										
	84	Chiff Ld	2										
	85	CharanLd	2										
	86	Voice Ld	2										
	87	Fifth Ld	2										
	88	Bass &Ld	2										
Synth Pad	89	NewAgePd	2										
	90	Warm Pad	2										
	91	PolySyPd	2										
	92	ChoirPad	2										
	93	BowedPad	2										
	94	MetalPad	2										
	95	Halo Pad	2										
	96	SweepPad	2										
Synth Effects	97	Rain	2										
	98	SoundTrk	2										
	99	Crystal	2									SynDrCmp	2
	100	Atmosphr	2										
	101	Bright	2										
	102	Goblins	2										
	103	Echoes	2										
	104	Sci-Fi	2							EchoPad2	2		
Ethnic	105	Sitar	1										
	106	Banjo	1										
	107	Shamisen	1										
	108	Koto	1										
	109	Kalimba	1										
	110	Bagpipe	2										
	111	Fiddle	1										
	112	Shanai	1										
Percussive	113	TnklBell	2										
	114	Agogo	2										
	115	SteelDrm	2										
	116	WoodBlok	1										
	117	TaikoDrm	1										
	118	MelodTom	2										
	119	Syn.Drum	1										
	120	RevCymb1	1										
Sound Effects	121	FretNoiz	2										
	122	BrthNoiz	2										
	123	Seashore	2										
	124	Tweet	2										
	125	Telephone	1										
	126	Helicptr	1										
	127	Applause	1										
	128	Gunshot	1										

Bank 0と同じ音色が入っています。



# XG Voice List (ノーマルボイス)

## Bank Select MSB=000, LSB= バンクナンバー

Instrument Group	Pgm #	Release		Rezo Sweep		Muted		Detune 1		Detune 2		
		Bank 0	EL	Bank 25	EL	Bank 27	EL	Bank 28	EL	Bank 32	EL	Bank 33
↓ 3ページ続き... ↓												
Reed	65	SprnoSax	1									
	66	Alto Sax	1									
	67	TenorSax	1									
	68	Bari. Sax	1									
	69	Oboe	2									
	70	Eng.Horn	1									
	71	Bassoon	1									
	72	Clarinet	1									
Pipe	73	Piccolo	1									
	74	Flute	1									
	75	Recorder	1									
	76	PanFlute	1									
	77	Bottle	2									
	78	Shakhchi	2									
	79	Whistle	1									
	80	Ocarina	1									
Synth Lead	81	SquareLd	2									
	82	Saw.Lead	2	WaspySyn	2							
	83	CaliopLd	2									
	84	Chiff Ld	2									
	85	CharanLd	2									
	86	Voice Ld	2									
	87	Fifth Ld	2									
	88	Bass &Ld	2									
Synth Pad	89	NewAgePd	2									
	90	Warm Pad	2									
	91	PolySyPd	2									
	92	ChoirPad	2									
	93	BowedPad	2									
	94	MetalPad	2									
	95	Halo Pad	2									
Synth Effects	96	SweepPad	2			Converge	2					
	97	Rain	2									
	98	SoundTrk	2			Prologue	2					
	99	Crystal	2									
	100	Atmosphr	2									
	101	Bright	2									
	102	Goblins	2									
Ethnic	103	Echoes	2									
	104	Sci-Fi	2									
	105	Sitar	1						DetSitar	2		
	106	Banjo	1					MuteBnjo	1			
	107	Shamisen	1									
	108	Koto	1									
	109	Kalimba	1									
Percussive	110	Bagpipe	2									
	111	Fiddle	1									
	112	Shanai	1									
	113	TnklBell	2									
	114	Agogo	2									
	115	SteelDrm	2									
	116	WoodBlok	1									
	117	TaikoDrm	1									
118	MelodTom	2										
Sound Effects	119	Syn.Drum	1									
	120	RevCymb1	1									
	121	FretNoiz	2									
	122	BrthNoiz	2									
	123	Seashore	2									
	124	Tweet	2									
	125	Telephone	1									
	126	Helicptr	1									
	127	Applause	1									
	128	Gunshot	1									

Bank 0と同じ音色が入っています。



# XG Voice List (ノーマルボイス)

Bank Select MSB=000, LSB= バンクナンバー

Instrument Groupe	Pgm #	Velo-Switch Velo-Xfade other wave															
		Bank 0	EL	Bank 41	EL	Bank 42	EL	Bank 43	EL	Bank 45	EL	Bank 64	EL				
↓ 5ページ続き... ↓																	
Reed	65	SprnoSax	1														
	66	Alto Sax	1					HyprAlto	2								
	67	TenorSax	1	SoftTenr	2									TnrSax 2	1		
	68	Bari. Sax	1														
	69	Oboe	2														
	70	Eng.Horn	1														
	71	Bassoon	1														
	72	Clarinet	1														
Pipe	73	Piccolo	1														
	74	Flute	1														
	75	Recorder	1														
	76	PanFlute	1											PanFlut2	1		
	77	Bottle	2														
	78	Shakhchi	2														
	79	Whistle	1														
	80	Ocarina	1														
Synth Lead	81	SquareLd	2											Mellow	2		
	82	Saw.Lead	2	Dr. Lead	2						VeloLead	2					
	83	CaliopLd	2											Vent Syn	2		
	84	Chiff Ld	2											Rubby	2		
	85	CharanLd	2											DistLead	2		
	86	Voice Ld	2											VoxLead	2		
	87	Fifth Ld	2														
	88	Bass &Ld	2											Fat&Prky	2		
Synth Pad	89	NewAgePd	2											Fantasy2	2		
	90	Warm Pad	2											Horn Pad	2		
	91	PolySyPd	2											PolyPd80	2		
	92	ChoirPad	2											Heaven2	2		
	93	BowedPad	2											Glacier	2		
	94	MetalPad	2											Tine Pad	2		
	95	Halo Pad	2														
	96	SweepPad	2											PolarPad	2		
Synth Effects	97	Rain	2								ClaviPad	2		HrmoRain	2		
	98	SoundTrk	2											Ancestrl	2		
	99	Crystal	2	ClearBel	2	ChorBell	2							SynMalet	1		
	100	Atmosphr	2											NylnHarp	2		
	101	Bright	2											FantaBel	2		
	102	Goblins	2											GobSyn	2		
	103	Echoes	2											EchoBell	2		
	104	Sci-Fi	2											Starz	2		
Ethnic	105	Sitar	1														
	106	Banjo	1														
	107	Shamisen	1														
	108	Koto	1														
	109	Kalimba	1											BigKalim	2		
	110	Bagpipe	2														
	111	Fiddle	1														
	112	Shanai	1											Shanai2	1		
Percussive	113	TnklBell	2														
	114	Agogo	2														
	115	SteelDrm	2														
	116	WoodBlok	1														
	117	TaikoDrm	1														
	118	MelodTom	2											Mel Tom2	1		
	119	Syn.Drum	1											Ana Tom	1		
	120	RevCymb1	1											Rev Cym2	1		
Sound Effects	121	FretNoiz	2														
	122	BrthNoiz	2														
	123	Seashore	2														
	124	Tweet	2														
	125	Telephone	1														
	126	Helicptr	1														
	127	Applause	1														
	128	Gunshot	1														

Bank 0と同じ音色が入っています。



# XG Voice List (ノーマルボイス)

Bank Select MSB=000, LSB= バンクナンバー

Instrument Group	Pgm #	Bank 0	EL	Bank 72	EL	Bank 96	EL	Bank 97	EL	Bank 98	EL	Bank 99	EL
↓ 7ページ続き... ↓													
Reed	65	SprnoSax	1										
	66	Alto Sax	1										
	67	TenorSax	1										
	68	Bari. Sax	1										
	69	Oboe	2										
	70	Eng.Horn	1										
	71	Bassoon	1										
	72	Clarinet	1			BassClar	1						
Pipe	73	Piccolo	1										
	74	Flute	1										
	75	Recorder	1										
	76	PanFlute	1			Kawala	2						
	77	Bottle	2										
	78	Shakhchi	2										
	79	Whistle	1										
	80	Ocarina	1										
Synth Lead	81	SquareLd	2										
	82	Saw.Lead	2			Seq Ana	2						
	83	CaliopLd	2										
	84	Chiff Ld	2										
	85	CharanLd	2										
	86	Voice Ld	2										
	87	Fifth Ld	2										
	88	Bass &Ld	2										
Synth Pad	89	NewAgePd	2										
	90	Warm Pad	2										
	91	PolySyPd	2										
	92	ChoirPad	2										
	93	BowedPad	2										
	94	MetalPad	2										
	95	Halo Pad	2										
	96	SweepPad	2										
Synth Effects	97	Rain	2										
	98	SoundTrk	2										
	99	Crystal	2	Gamelmba	2								
	100	Atmosphr	2										
	101	Bright	2			Smokey	2						
	102	Goblins	2	Puffy	2	BelChoir	2						
	103	Echoes	2										
	104	Sci-Fi	2										
Ethnic	105	Sitar	1			Tambra	2	Tamboura	2				
	106	Banjo	1			Rabab	2	Gopichnt	2	Oud	2		
	107	Shamisen	1			Tsugaru	2						
	108	Koto	1			T. Koto	2	Kanoon	2				
	109	Kalimba	1										
	110	Bagpipe	2										
	111	Fiddle	1										
	112	Shanai	1			Pungi	1	Hichriki	2				
Percussive	113	TnklBell	2			Bonang	2	Gender	2	Gamelan	2	S.Gamlan	2
	114	Agogo	2			Atrigane	2						
	115	SteelDrm	2			Tablas	2	GlasPerc	2	ThaiBell	2		
	116	WoodBlok	1			Castanet	1						
	117	TaikoDrm	1			Gr.Cassa	1						
	118	MelodTom	2										
	119	Syn.Drum	1										
	120	RevCymb1	1			RevSnar1	1	RevSnar2	1	RevKick1	1	RevConBD	1
Sound Effects	121	FretNoiz	2										
	122	BrthNoiz	2										
	123	Seashore	2										
	124	Tweet	2										
	125	Telephone	1										
	126	Helicptr	1										
	127	Applause	1										
	128	Gunshot	1										

Bank 0と同じ音色が入っています。





# TG 300-B Voice List (ノーマルボイス)

**Bank Select MSB=** バンクナンバー, **LSB=000**

Instrument Groupe	Pgm #	Bank 0	EL	Bank 1	EL	Bank 2	EL	Bank 3	EL	Bank 4	EL	Bank 5	EL
Piano	1	GrandPno	1										
	2	BritePno	1										
	3	E.Grand	2	EIGrPno1	2	EIGrPno2	2						
	4	HnkyTonk	2										
	5	E.Piano1	2										
	6	E.Piano2	2										
	7	Harpsi.	1										
	8	Clavi.	2										
Chromatic Percussion	9	Celesta	1										
	10	Glocken	1										
	11	MusicBox	2										
	12	Vibes	1	Hard Vibe	2								
	13	Marimba	1										
	14	Xylophon	1										
	15	TubulBel	1										
	16	Dulcimer	1	Dulcimr 2	2								
Organ	17	DrawOrgn	1	70sDrOr1	2								
	18	PercOrgn	1	70sPcOr1	2								
	19	RockOrgn	2										
	20	ChrchOrg	2										
	21	ReedOrgn	1										
	22	Acordion	2										
	23	Harmnica	1	Harmo 2	2								
	24	TangoAcd	2										
Guitar	25	NylonGtr	1										
	26	SteelGtr	1										
	27	Jazz Gtr	1	MelloGtr	1								
	28	CleanGtr	1										
	29	Mute.Gtr	1	Mu.DstGt	2								
	30	Ovrdrive	1										
	31	Dist.Gtr	1	DistGtr2	2	DistGtr3	2						
	32	GtrHarmo	1										
Bass	33	Aco.Bass	1										
	34	FngrBass	1	FngBass2	2	JazzBass	1						
	35	PickBass	1										
	36	Fretless	1	Fretles2	2	Fretles3	2	Fretles4	2	SynFretl	2	Smooth	2
	37	SlapBas1	1										
	38	SlapBas2	1										
	39	SynBass1	1	SynBa1Dk	1								
	40	SynBass2	2	ClkSynBa	2	ModulrBa	2	Seq Bass	2				
Strings	41	Violin	1										
	42	Viola	1										
	43	Cello	1										
	44	Contrabs	1										
	45	Trem.Str	1										
	46	Pizz.Str	1										
	47	Harp	1										
	48	Timpani	1										
Ensemble	49	Strings1	1	Slow Str	1								
	50	Strings2	1	70s Str	1								
	51	Syn.Str1	2	SynStr4	2								
	52	Syn.Str2	2										
	53	ChoirAah	1										
	54	VoiceDoo	1										
	55	SynVoice	1										
	56	Orch.Hit	2	OrchHit2	2								
Brass	57	Trumpet	1	Trumpet2	1								
	58	Trombone	1	Trmbone2	2								
	59	Tuba	1	Tuba 2	1								
	60	Mute.Trp	1										
	61	Fr.Horn	2	FrHorn2	2								
	62	BrasSect	1										
	63	SynBras1	2	PolyBrss	2								
	64	SynBras2	1	Soft Brs	2								

↓ 21ページへ続く... ↓

Bank 0と同じ音色が入っています。

Bank 6	EL	Bank 7	EL	Bank 8	EL	Bank 9	EL	Bank 10	EL	Bank 11	EL	Bank 16	EL
				GrndPnoK	1							MelloGrP	1
				BritPnoK	1								
				ElGrPnoK	2								
				HnkyTnkK	2								
				Chor.EP1	2							VX EI.P1	2
				Chor.EP2	2							VX EI.P2	2
				Harpsi.3	2							Harpsi.K	1
				Clavi. K	1								
				VibesK	1								
				MarimbaK	1							Balafon	2
				ChrchBel	2	Carillon	2						
				Cimbalom	2								
				DetDrwOr	2	70sDrOr2	2					60sDrOr1	2
				DetPrcOr	2								
				RotaryOr	2							SloRotar	2
				ChurOrg2	2							ChurOrg3	2
				AccordIt	2								
				Ukulele	1							NylonGt3	2
				12StrGtr	2	Nyln&Stl	2					Mandolin	2
				PdISteel	1								
				ChorusGt	2								
				FunkGtr1	2							FunkGtr2	2
				FeedbkGt	2	FeedbGt2	2					PowerGt1	2
				GtFeedbk	1							AcoHarmo	1
				MutePkBa	1								
				ResoSlap	1								
				AcidBass	1	FastResB	1	TeknoBa	2			ResoBass	1
				DX Bass	2	X WireBa	2					RubberBa	2
				SlowVln	1								
				SlwTrStr	1	Susp Str	2						
				Orchestr	2	Orchstr2	2	TremOrch	2	ChoirStr	2	S.Strngs	2
				LegatoSt	2	Warm Str	2	S.SlwStr	2				
				Syn Str 3	2								
				S.Choir	2	MelChoir	2						
				SynVox2	2								
				Impact	2	BrssStab	2	DoublHit	2			LoFiRave	2
				FluglHrn	1								
				FrHrSolo	1							HornOrch	2
				BrssSec2	2							BrssFall	1
				SynBras3	2	QuackBr	2					AnaBrss1	2
				SynBras4	2							AnaBrss2	2

↓ 22ページへ続く... ↓

# TG 300-B Voice List (ノーマルボイス)

**Bank Select MSB=** バンクナンバー, **LSB=000**

Instrument Groupe	Pgm #	Bank 0	EL	Bank 17	EL	Bank 18	EL	Bank 19	EL	Bank 24	EL	Bank 25	EL
Piano	1	GrandPno	1										
	2	BritePno	1										
	3	E.Grand	2										
	4	HnkyTonk	2										
	5	E.Piano1	2							60sEI.P	1	HardEI.P	2
	6	E.Piano2	2							DX Hard	2		
	7	Harpsi.	1							Harpsi.2	2		
	8	Clavi.	2										
Chromatic Percussion	9	Celesta	1										
	10	Glocken	1										
	11	MusicBox	2										
	12	Vibes	1										
	13	Marimba	1	Balafon2	2					Log Drum	2		
	14	Xylophon	1										
	15	TubulBel	1										
	16	Dulcimer	1										
Organ	17	DrawOrgn	1	60sDrOr2	2	60sDrOr3	2			CheezOrg	2		
	18	PercOrgn	1										
	19	RockOrgn	2							FstRotar	2		
	20	ChrchOrg	2							OrgFlute	2		
	21	ReedOrgn	1										
	22	Acordion	2										
	23	Harmnica	1										
	24	TangoAcid	2										
Guitar	25	NylonGtr	1							VelGtHrm	2		
	26	SteelGtr	1										
	27	Jazz Gtr	1										
	28	CleanGtr	1										
	29	Mute.Gtr	1										
	30	Ovrdrive	1										
	31	Dist.Gtr	1	PowerGt2	2	Dst.5ths	2			RockRthm	2	RkRythm2	2
	32	GtrHarmo	1										
Bass	33	Aco.Bass	1										
	34	FngrBass	1										
	35	PickBass	1										
	36	Fretless	1										
	37	SlapBas1	1										
	38	SlapBas2	1										
	39	SynBass1	1										
	40	SynBass2	2	SynBa2Dk	1	MelloSB2	1	SmthBa 2	2				
Strings	41	Violin	1										
	42	Viola	1										
	43	Cello	1										
	44	Contrabs	1										
	45	Trem.Str	1										
	46	Pizz.Str	1										
	47	Harp	1										
	48	Timpani	1										
Ensemble	49	Strings1	1							VeloStr	2		
	50	Strings2	1										
	51	Syn.Str1	2										
	52	Syn.Str2	2										
	53	ChoirAah	1										
	54	VoiceDoo	1										
	55	SynVoice	1										
	56	Orch.Hit	2										
Brass	57	Trumpet	1							BriteTrp	2	WarmTrp	2
	58	Trombone	1										
	59	Tuba	1										
	60	Mute.Trp	1										
	61	Fr.Horn	2										
	62	BrasSect	1										
	63	SynBras1	2										
	64	SynBras2	1	VelBras2	2								

↓ 23ページへ続く... ↓

Bank 0と同じ音色が入っています。

Bank 26	EL	Bank 32	EL	Bank 33	EL	Bank 40	EL	Bank 126	EL	Bank 127	EL
								A-Piano1	2	a.piano1	1
								A-Piano2	2	a.piano2	1
								A-Piano3	2	a.piano3	1
								A-Piano4	2	e.piano1	1
MelloEP1	2	El.Pno1K	1					A-Piano5	1	e.piano2	1
		El.Pno2K	1					A-Piano6	1	e.piano3	1
								A-Piano7	1	e.piano4	1
								E-Piano1	2	hnkytnk	2
								E-Piano2	2	e.organ1	2
								E-Piano3	2	e.organ2	2
								A-Guitr1	1	e.organ3	1
								A-Guitr2	2	e.organ4	1
								A-Guitr3	2	pipeorg1	2
								E-Guitr1	2	pipeorg2	2
								E-Guitr2	1	pipeorg3	2
								Slap-1	2	acordion	2
		DrawOrg2	2	EvenBar	2	Organ Ba	1	Slap-2	2	harpsi1	1
		PercOrg2	2					Slap-3	2	harpsi2	2
								Slap-4	2	harpsi3	1
		TrmOrgFl	2					Slap-5	2	clavi1	1
								Slap-6	2	clavi2	1
								Slap-7	2	clavi3	1
								Slap-8	2	celesta1	1
								Finger-1	1	celesta2	1
		NylonGt2	1			LequintG	1	Finger-2	2	synbras1	2
		SteelGt2	1					Picked-1	1	synbras2	2
								Picked-2	2	synbras3	2
								FretlsBs	1	synbras4	2
								A-Bass	2	synbass1	1
								Choir-1	1	synbass2	1
								Choir-2	1	synbass3	2
								Choir-3	2	synbass4	1
								Choir-4	2	newagepd	2
								Strngs-1	2	synharmo	2
								Strngs-2	2	choir pd	2
								Strngs-3	2	bowed pd	2
								Strngs-4	2	soundtrk	2
								E-Organ1	2	atmosphr	2
								E-Organ2	2	syn warm	2
								E-Organ3	2	synfunny	1
								E-Organ4	2	synecho1	2
								E-Organ5	2	rain	2
								E-Organ6	2	synoboe	2
								E-Organ7	2	synecho2	2
								E-Organ8	2	synsolo	2
								E-Organ9	2	synrdorg	2
								SoftTP-1	1	synbell	1
								SoftTP-2	1	squareld	2
								TP/TRB-1	1	strsect1	2
								TP/TRB-2	1	strsect2	2
								TP/TRB-3	1	strsect3	2
								TP/TRB-4	1	pizz.str	1
		Ch.Aahs2	2					TP/TRB-5	2	violin 1	2
								TP/TRB-6	2	violin 2	1
								Sax-1	1	cello 1	1
								Sax-2	1	cello 2	1
								Sax-3	1	contrabs	1
								Sax-4	2	harp 1	1
								Brass-1	1	harp 2	1
								Brass-2	1	guitar 1	1
								Brass-3	2	guitar 2	1
								Brass-4	2	elecgr1	2
								Brass-5	2	elecgr2	2
								Orch-Hit	1	sitar	1

↓ 24ページへ続く... ↓

# TG 300-B Voice List (ノーマルボイス)

**Bank Select MSB=** バンクナンバー, **LSB=000**

Instrument Group	Pgm #	Bank 0	EL	Bank 1	EL	Bank 2	EL	Bank 3	EL	Bank 4	EL	Bank 5	EL
↓ 17ページ続き... ↓													
Reed	65	SprnoSax	1										
	66	Alto Sax	1										
	67	TnrSax 2	1										
	68	Bari.Sax	1										
	69	Oboe	2										
	70	Eng.Horn	1										
	71	Bassoon	1										
	72	Clarinet	1										
Pipe	73	Piccolo	1										
	74	Flute	1										
	75	Recorder	1										
	76	PanFlute	1										
	77	Bottle	2										
	78	Shakhchi	2										
	79	Whistle	1										
	80	Ocarina	1										
Synth Lead	81	SquareLd	2	Square 2	1	Hollow	1	Mellow	2	SoloSine	2	Shmoog	2
	82	Saw.Lead	2	Saw 2	1	PulseSaw	2	ThickSaw	2	Big Lead	2	VeloLead	2
	83	CaliopLd	2	Vent Syn	2	Pure Pad	2						
	84	Chiff Ld	2										
	85	CharanLd	2										
	86	Voice Ld	2										
	87	Fifth Ld	2	Big Five	2								
	88	Bass &Ld	2	Big&Low	2	Fat&Prky	2						
Synth Pad	89	NewAgePd	2	Fantasy2	2								
	90	Warm Pad	2	ThickPad	2	Horn Pad	2	RotarStr	2	Soft Pad	2		
	91	PolySyPd	2	PolyPd80	2								
	92	ChoirPad	2	Heaven2	2								
	93	BowedPad	2										
	94	MetalPad	2	Tine Pad	2	Pan Pad	2						
	95	Halo Pad	2										
	96	SweepPad	2	PolarPad	2								
Synth Effects	97	Rain	2	HrrmoRain	2	AfrcnWnd	2						
	98	SoundTrk	2	Ancestrl	2	Prologue	2						
	99	Crystal	2	SynMalet	1	SftCryst	2	RndGlock	2	LoudGlok	2	GlockChi	2
	100	Atmosphr	2	WarmAtms	2	NylnHarp	2	Harp Vox	2	HollwRls	2	NylonEP	2
	101	Bright	2										
	102	Goblins	2	GobSyn	2	50sSciFi	2						
	103	Echoes	2	EchoBell	2	Echo Pan	2	EchoPad2	2	Big Pan	2	Reso Pan	2
	104	Sci-Fi	2	Starz	2								
Ethnic	105	Sitar	1	Sitar 2	2	DetSitar	2						
	106	Banjo	1	MuteBnjo	1								
	107	Shamisen	1	Tsugaru	2								
	108	Koto	1										
	109	Kalimba	1										
	110	Bagpipe	2										
	111	Fiddle	1										
	112	Shanai	1	Shanai 2	1								
Percussive	113	TnklBell	2										
	114	Agogo	2										
	115	SteelDrm	2										
	116	WoodBlok	1										
	117	TaikoDrm	1										
	118	MelodTom	2	Real Tom	2								
	119	Syn.Drum	1										
	120	RevCymb1	1	Rev Cym2	1								
Sound Effects	121	FretNoiz	2	CuttngNz	1	Str Slap	1	CttngNz2	2	DstCutNz	2	B.Slide	2
	122	BrthNoiz	2	Fl.KClik	1								
	123	Seashore	2	Rain	1	Thunder	1	Wind	1	Stream	2	Bubble	2
	124	Tweet	2	Dog	1	Horse	1	Bird 2	1	Kitty	1	Growl	1
	125	Telephone	1	Tel.Dial	1	DoorSqek	1	DoorSlam	1	Scratch	1	WindChm	1
	126	Helicptr	1	CarEngin	1	Car Stop	1	Car Pass	1	CarCrash	1	Siren	2
	127	Applause	1	Laughing	1	Scream	1	Punch	1	Heart	1	FootStep	1
	128	Gunshot	1	MchinGun	1	LaserGun	2	Xplosion	2				

Bank 0と同じ音色が入っています。

Bank 6	EL	Bank 7	EL	Bank 8	EL	Bank 9	EL	Bank 10	EL	Bank 11	EL	Bank 16	EL
↓ 18ページ続き... ↓													
				HyprAlto	2								
				BrthTnSx	2								
				BassClar	1								
				Kawala	2								
LMSquare	2			SineLead	1								
HeavySyn	2	DynaSaw	1	Dr. Lead	2							WaspySyn	2
				DistLead	2								
				Converge	2	Shwimmer	2	Celstial	2				
				ClaviPad	2								
				Rave	2								
ClearBel	2	XmasBell	2	VibeBell	2	DigiBell	2					ChorBell	2
AtmosPad	2												
SynPiano	2												
				Tambra	2							Tamboura	2
				Rabab	2							Gopichnt	2
				T. Koto	2							Kanoon	2
				Pungi	1							Hichrki	2
				Bonang	2	Gender	2	Gamelan	2	S.Gamlan	2	Rama Cym	2
				Atrigane	2								
				Castanet	1								
				Gr.Cassa	1								
				Mel Tom2	1	Rock Tom	2						
				Ana Tom	1	ElecPerc	2						
				RevSnar1	1	RevSnar2	1					RevKick1	1
P.Scrape	1												
Scratch2	2												
Train	1	Jetplane	2	Starship	2	Burst	2					Coaster	2

# TG 300-B Voice List (ノーマルボイス)

**Bank Select MSB=** バンクナンバー, **LSB=000**

Instrument Group	Pgm #	Bank 0	EL	Bank 17	EL	Bank 18	EL	Bank 19	EL	Bank 24	EL	Bank 25	EL
↓ 19ページ続き... ↓													
Reed	65	SprnoSax	1										
	66	Alto Sax	1										
	67	TnrSax 2	1										
	68	Bari.Sax	1										
	69	Oboe	2										
	70	Eng.Horn	1										
	71	Bassoon	1										
	72	Clarinet	1										
Pipe	73	Piccolo	1										
	74	Flute	1										
	75	Recorder	1										
	76	PanFlute	1										
	77	Bottle	2										
	78	Shakhchi	2										
	79	Whistle	1										
	80	Ocarina	1										
Synth Lead	81	SquareLd	2										
	82	Saw.Lead	2										
	83	CaliopLd	2										
	84	Chiff Ld	2										
	85	CharanLd	2										
	86	Voice Ld	2										
	87	Fifth Ld	2										
	88	Bass &Ld	2										
Synth Pad	89	NewAgePd	2										
	90	Warm Pad	2										
	91	PolySyPd	2										
	92	ChoirPad	2										
	93	BowedPad	2										
	94	MetalPad	2										
	95	Halo Pad	2										
	96	SweepPad	2										
Synth Effects	97	Rain	2										
	98	SoundTrk	2										
	99	Crystal	2	AirBells	2	BellHarp	2	Gamelmba	2				
	100	Atmosphr	2										
	101	Bright	2										
	102	Goblins	2										
	103	Echoes	2										
	104	Sci-Fi	2										
Ethnic	105	Sitar	1										
	106	Banjo	1							Oud	2		
	107	Shamisen	1										
	108	Koto	1										
	109	Kalimba	1										
	110	Bagpipe	2										
	111	Fiddle	1										
	112	Shanai	1										
Percussive	113	TnklBell	2										
	114	Agogo	2										
	115	SteelDrm	2										
	116	WoodBlok	1										
	117	TaikoDrm	1										
	118	MelodTom	2										
	119	Syn.Drum	1										
	120	RevCymb1	1	RevConBD	1					Rev Tom1	1	Rev Tom2	1
Sound Effects	121	FretNoiz	2										
	122	BrthNoiz	2										
	123	Seashore	2										
	124	Tweet	2										
	125	Telephone	1										
	126	Helicptr	1										
	127	Applause	1										
	128	Gunshot	1										

Bank 0と同じ音色が入っています。



Bank 26	EL	Bank 32	EL	Bank 33	EL	Bank 40	EL	Bank 126	EL	Bank 127	EL
↓ 20ページ続き... ↓											
								Silence		a.bass 1	1
								Silence		a.bass 2	1
								Silence		e.bass 1	1
								Silence		e.bass 2	1
								Silence		slapbas1	1
								Silence		slapbas2	1
								Silence		fretles1	1
								Silence		fretles2	1
								Silence		flute1	1
								Silence		flute2	1
								Silence		piccolo1	1
								Silence		piccolo2	2
								Silence		recorder	1
								Silence		panpipes	2
								Silence		sax1	2
								Silence		sax2	1
								Silence		sax3	1
								Silence		sax4	1
								Silence		clarint1	1
								Silence		clarint2	1
								Silence		oboe	1
								Silence		eng.horn	1
								Silence		bassoon	1
								Silence		harmnica	1
								Silence		trumpet1	1
								Silence		trumpet2	1
								Silence		trmbone1	2
								Silence		trmbone2	2
								Silence		fr.horn1	1
								Silence		fr.horn2	2
								Silence		tuba	2
								Silence		brssect1	1
								Silence		brssect2	2
								Silence		vibe1	1
								Silence		vibe2	1
								Silence		symallet	1
								Silence		maletwin	2
								Silence		glocken	2
								Silence		tubulbel	1
								Silence		xylophon	1
								Silence		marimba	2
								Silence		koto	1
								Silence		sho	2
								Silence		shakhchi	2
								Silence		whistle1	2
								Silence		whistle2	1
								Silence		bottle	2
								Silence		breath	2
								Silence		timpani	1
								Silence		melotom	1
								Silence		deepsnar	1
								Silence		e.perc1	1
								Silence		e.perc2	1
								Silence		taiko	1
								Silence		taikorim	1
								Silence		cymbal	2
								Silence		castanet	1
								Silence		triangle	1
								Silence		orchehit	1
								Silence		telephone	1
								Silence		bird	1
								Silence		jam	1
								Silence		efctwatr	2
								Silence		efctjngl	2

## C/M Voice List (ノーマルボイス)

Pgm#	TYPE1 Part1 ~ 9	TYPE2 Part11 ~ 16
1	a.piano1	A-Piano1
2	a.piano2	A-Piano2
3	a.piano3	A-Piano3
4	e.piano1	A-Piano4
5	e.piano2	A-Piano5
6	e.piano3	A-Piano6
7	e.piano4	A-Piano7
8	hnkytnk	E-Piano1
9	e.organ1	E-Piano2
10	e.organ2	E-Piano3
11	e.organ3	A-Guitr1
12	e.organ4	A-Guitr2
13	pipeorg1	A-Guitr3
14	pipeorg2	E-Guitr1
15	pipeorg3	E-Guitr2
16	acordion	Slap-1
17	harpsi1	Slap-2
18	harpsi2	Slap-3
19	harpsi3	Slap-4
20	clavi1	Slap-5
21	clavi2	Slap-6
22	clavi3	Slap-7
23	celesta1	Slap-8
24	celesta2	Finger-1
25	synbras1	Finger-2
26	synbras2	Picked-1
27	synbras3	Picked-2
28	synbras4	FretlsBs
29	synbass1	A-Bass
30	synbass2	Choir-1
31	synbass3	Choir-2
32	synbass4	Choir-3
33	newagepd	Choir-4
34	synharmo	Strngs-1
35	choir pd	Strngs-2
36	bowed pd	Strngs-3
37	soundtrk	Strngs-4
38	atmosphr	E-Organ1
39	syn warm	E-Organ2
40	synfunny	E-Organ3
41	synecho1	E-Organ4
42	rain	E-Organ5
43	synoboe	E-Organ6
44	synecho2	E-Organ7
45	synsolo	E-Organ8
46	synrdorg	E-Organ9
47	synbell	SoftTP-1
48	squareld	SoftTP-2
49	strsect1	TP/TRB-1
50	strsect2	TP/TRB-2
51	strsect3	TP/TRB-3
52	pizz.str	TP/TRB-4
53	violin 1	TP/TRB-5
54	violin 2	TP/TRB-6
55	cello 1	Sax-1
56	cello 2	Sax-2
57	contrabs	Sax-3
58	harp 1	Sax-4
59	harp 2	Brass-1
60	guitar 1	Brass-2
61	guitar 2	Brass-3
62	elecgr1	Brass-4
63	elecgr2	Brass-5
64	sitar	Orch-Hit

Pgm#	TYPE1 Part1 ~ 9	TYPE2 Part11 ~ 16
65	a.bass 1	Silence
66	a.bass 2	Silence
67	e.bass 1	Silence
68	e.bass 2	Silence
69	slapbas1	Silence
70	slapbas2	Silence
71	fretles1	Silence
72	fretles2	Silence
73	flute1	Silence
74	flute2	Silence
75	piccolo1	Silence
76	piccolo2	Silence
77	recorder	Silence
78	panpipes	Silence
79	sax1	Silence
80	sax2	Silence
81	sax3	Silence
82	sax4	Silence
83	clarint1	Silence
84	clarint2	Silence
85	oboe	Silence
86	eng.horn	Silence
87	bassoon	Silence
88	harmnica	Silence
89	trumpet1	Silence
90	trumpet2	Silence
91	trmbone1	Silence
92	trmbone2	Silence
93	fr.horn1	Silence
94	fr.horn2	Silence
95	tuba	Silence
96	brssect1	Silence
97	brssect2	Silence
98	vibe1	Silence
99	vibe2	Silence
100	symallet	Silence
101	maletwin	Silence
102	glocken	Silence
103	tubulbel	Silence
104	xylophon	Silence
105	marimba	Silence
106	koto	Silence
107	sho	Silence
108	shakhchi	Silence
109	whistle1	Silence
110	whistle2	Silence
111	bottle	Silence
112	breath	Silence
113	timpani	Silence
114	melotom	Silence
115	deepsnar	Silence
116	e.perc1	Silence
117	e.perc2	Silence
118	taiko	Silence
119	taikorim	Silence
120	cymbal	Silence
121	castanet	Silence
122	triangle	Silence
123	orchehit	Silence
124	telephone	Silence
125	bird	Silence
126	jam	Silence
127	efctwatr	Silence
128	efctjngl	Silence

# Performance List (パフォーマンスリスト)

Pgm#	Category	Performance Name	Comment
1	CO	Flower	ハーブとコーラスのレイヤー音色です。
2	AP	ConcertGrand	共鳴感までも再現したリッチなフルコンサートグランドピアノです。
3	OR	BackyardOR	バックキングに適したJaxx系のオルガンです。
4	GT	CleanEG	アルペジオ弾きに適したクリーンなエレクトリックギターです。
5	BA	VacuumBass	フェイザーの効いた重みのあるベースです。
6	ST	Rich Strings	ペロシティでアタックと厚みが増えるストリングスです。
7	BR	Punch Brass	生とシンセを混ぜたパンチのあるブラスです。
8	PD	Easter	リード風にも弾けるエスニック風パッド音色です。
9	SC/LD	Solomon	コンプ風にも弾けるシンセリードです。
10	FX	Creation	ポルタメントを効果的に使ったFX音色で、MWを上げるとさらに音が変わります。
11	SE	Sea View	深海を行く気分で弾いて下さい。
12	CO	Gabriel CP	ヤマハC P 8 0の特徴を生かしたパッドとのレイヤー音色です。
13	CO	MIDI Grand	エレピとピアノのレイヤー。MWを上げるとピアノとパッドになります。
14	OR	Church Organ	荘厳さの漂う教会オルガンです。
15	GT	Metal Dist	タッチによるピッキングハーモニクス、B1から下のスクラッチ音が特長のヘビーメタル系ディストーションギターです。
16	BA	SynJazzBass	ジャズベースの響きを持ったシンセベースです。
17	ST	Horn&Strings	ホルンの混じった使い勝手の良いストリングスです。
18	BR	TijuanaBrass	6 0年代風のソフトなブラスセクションです。
19	PD	Blue&Blue	透明感のあるパッドです。
20	SC	Mega Studio	SEQフレーズやバックキングのきざみに適したシンセ音色です。
21	PD	Aquamarine	水中をイメージしたパッド音色です。
22	ET	Asian Dance	東南アジア的イメージのエスニックベルサウンド。
23	SC	Clavorgue	クラビとオルガンをブレンドさせた音色です。
24	EP	Phazed EP	フェイザーの効いたエレピです。
25	OR	Old Days OR	MWでレスリースピードが変えられるパーカッシブオルガンです。
26	GT	Wah Guitar	オートワウによるファンキーなエレクトリックギターです。
27	BA	WaterPhazeBs	ペロシティによる音色変化が特徴的な重たいベースです。
28	ST	Hi Strings	生とシンセを混ぜたハイブリッドなストリングスです。
29	BR	CS80mind	ヤマハアナログシンセの名機CS 8 0のブラスです。
30	CH	Ooh Choir	エフェクトで揺らぎ感を持たせたコーラスです。
31	SC	Solid Funk	メタリックなアタックが特徴のコンプ音色です。
32	FX	Z-Hole	未知の世界へ吸い込まれるようなパッド音色です。
33	ET	Jungle Road	アフリカのジャングルをイメージした音色です。
34	CO	Jewel Box	オルゴールをアタックにしたパッド音色です。
35	EP	DX Lover	DX系のおいしい音をブレンドさせたリッチなエレピです。
36	OR	ProgressiveOR	プログレッシブロックにおいての代表的オルガンサウンド。MW1にてロータリースピーカー効果。
37	GT	12st Fantasy	1 2弦ギターの音色で、押し続けるとパッドが重なります。
38	BA	Porta Bass	ポルタメントの掛かったモノシンセベースです。
39	FX	Star Dust	普通はきらめきのあるパッドで、MWを上げるとさらに派手な変化が得られます。
40	BR	PowerSyn BR	リードとしても使えるパワフルなシンセブラス。
41	PD	White Train	眠りに誘われるような幻想的なパッドです。
42	LD	SyncoousticLD	シンセと生のコンビネーションリードです。
43	PD	FatEnsemble	アナログシンセ風の暖かいパッドです。
44	SE	SAMURAI!	三味線をメインにした時代劇の劇伴で使われそうな音色で、ペロシティで馬が鳴き、走ります。
45	CO	Nylon EP	DXエレピとアコースティックギターのレイヤーで、MWでパッドが重なります。
46	MK	Clav Westrn	古い感じのクラビ系音色です。
47	OR	Doors OR	重みのあるオルガンです。
48	BA	Slap Switch	ペロシティスプリットされたスラップベースです。
49	ST	Orchestra	強いペロシティでティンパニが出るオーケストラ音色です。
50	BR	Shot Brass	ブラスヒット風の音色です。
51	PD	Analog Age	暖かくて透明感のあるアナログシンセ系パッドです。
52	SC	Clababy	オートワウが特徴のシンセクラビです。
53	FX	To Heaven	ベル系の音が印象的なパッドです。
54	SE	Alien	謎の宇宙生物出現。強いペロシティでうめき声が聞こえます。
55	CO	1950's Jazz	古い年代風のウッドベースとピアノのスプリット音色です。
56	EP	Spector EP	MWを動かすと色々なタイプの音色が弾けるエレピです。
57	OR	Dream Organ	ベルのような音の混じった、夢に出てきそうなオルガンです。
58	RD	SoftSaxSect	Saxが4本混ざったマイルドなサクセスセクションです。
59	PD	Movie Pad	大きさと厚みのあるストリングス系パッドです。
60	LD	MonoWireLD	マイルドな中にワイヤ的な音もあるシンセリードです。
61	SC	Fat Comp	ブラス風にもリード風にも弾ける使い勝手の良いコンプ音色です。
62	LD	Sticky LD	ペロシティでのアタックの音色変化が特徴のシンセリードです。
63	FX	Space Legend	宇宙的なイメージのコーラス風パッド音色です。
64	SE	Devil'sHouse	悪魔の家をイメージした効果音。C3を境にタッチを強く弾くと悪魔の声と悲鳴が.....こっ、怖い!!

パフォーマンスのバンクセレクトは以下のように選びます。

PRE : MSB = 001, LSB = 000

INT : MSB = 002, LSB = 000

AP : acoustic piano BA : bass BR : brass CH : choir CO : combination ET : ethnic

EP : electric piano FX : synth SFX GT : guitar LD : synth lead MK : misc. piano / keyboard

OR : organ PD : synth pad RD : reed SC : synth comp SE : sound effects

ST : strings / orchestra

# XG Drum Map (ドラムボイス)

Bank MSB#	127				127				127				126			
Program #	1				2				9				17			
Note#	Note	Key off	Alternate assign	Standard Kit	Standard2 Kit	Room Kit	Rock Kit	Electro Kit	Analog Kit	Jazz Kit	Brush Kit	Classic Kit	SFX 1	SFX 2		
13	C# -1		3	Surdo Mute												
14	D -1		3	Surdo Open												
15	D# -1			Hi Q												
16	E -1			Whip Slap												
17	F -1		4	Scratch Push												
18	F# -1		4	Scratch Pull												
19	G -1			Finger Snap												
20	G# -1			Click Noise												
21	A -1			Metronome Click												
22	A# -1			Metronome Bell												
23	B -1			Seq Click L												
24	C 0			Seq Click H												
25	C# 0			Brush Tap												
26	D 0	O		Brush Swirl L												
27	D# 0			Brush Slap												
28	E 0	O		Brush Swirl H				Reverse Cymbal	Reverse Cymbal							
29	F 0	O		Snare Roll												
30	F# 0			Castanet				Hi Q	Hi Q							
31	G 0			Snare L			SD Rock M	Snare M	SD Rock H		Brush Slap L					
32	G# 0			Sticks												
33	A 0			Bass Drum L			Bass Drum M	Bass Drum H 4	Bass Drum M			Bass Drum L2				
34	A# 0			Open Rim Shot	Open Rim Shot 2											
35	B 0			Bass Drum M	Bass Drum M 2		Bass Drum H 3	BD Rock	BD Analog L			Gran Cassa				
36	C 1			Bass Drum H	Bass Drum H 2	BD Room	BD Rock	BD Gate	BD Analog H	BD Jazz	BD Soft	Gran Cassa Mute	Guitar Cutting Noise	Dial Tone		
37	C# 1			Side Stick					Analog Side Stick				Guitar Cutting Noise 2	Door Creaking		
38	D 1			Snare M	Snare M 2	SD Room L	SD Rock	SD Rock L	Analog Snare L		Brush Slap	Marching Sn M	Dist. Cut Noise	Door Slam		
39	D# 1			Hand Clap									String Slap	Scratch		
40	E 1			Snare H	Snare H 2	SD Room H	SD Rock Rim	SD Rock H	Analog Snare H		Brush Tap	Marching Sn H	Bass Slide	Scratch 2		
41	F 1			Floor Tom L	Floor Tom 1	Room Tom 1	Rock Tom 1	E Tom 1	Analog Tom 1	Jazz Tom 1	Brush Tom 1	Jazz Tom 1	Pick Scrape	Windchime		
42	F# 1		1	Hi-Hat Closed					Analog HH Closed 1					Telephone Ring 2		
43	G 1			Floor Tom H		Room Tom 2	Rock Tom 2	E Tom 2	Analog Tom 2	Jazz Tom 2	Brush Tom 2	Jazz Tom 2				
44	G# 1		1	Hi-Hat Pedal					Analog HH Closed 2							
45	A 1			Low Tom		Room Tom 3	Rock Tom 3	E Tom 3	Analog Tom 3	Jazz Tom 3	Brush Tom 3	Jazz Tom 3				
46	A# 1		1	Hi-Hat Open					Analog HH Open							
47	B 1			Mid Tom L		Room Tom 4	Rock Tom 4	E Tom 4	Analog Tom 4	Jazz Tom 4	Brush Tom 4	Jazz Tom 4				
48	C 2			Mid Tom H		Room Tom 5	Rock Tom 5	E Tom 5	Analog Tom 5	Jazz Tom 5	Brush Tom 5	Jazz Tom 5				
49	C# 2			Crash Cymbal 1					Analog Cymbal				Hand Cym.Open L			
50	D 2			High Tom		Room Tom 6	Rock Tom 6	E Tom 6	Analog Tom 6	Jazz Tom 6	Brush Tom 6	Jazz Tom 6				
51	D# 2			Ride Cymbal 1									Hand Cym.Closed L			
52	E 2			Chinese Cymbal									FL.Key Click	Engine Start		
53	F 2			Ride Cymbal Cup										Tire Screech		
54	F# 2			Tambourine										Car Passing		
55	G 2			Splash Cymbal										Crash		
56	G# 2			Cowbell					Analog Cowbell					Siren		
57	A 2			Crash Cymbal 2								Hand Cym.Open H		Train		
58	A# 2			Vibraslap										Jetplane		
59	B 2			Ride Cymbal 2								Hand Cym.Closed H		Starship		
60	C 3			Bongo H										Burst Noise		
61	C# 3			Bongo L										Coaster		
62	D 3			Conga H Mute					Analog Conga H					SbMarine		
63	D# 3			Conga H Open					Analog Conga M							
64	E 3			Conga L					Analog Conga L							
65	F 3			Timbale H												
66	F# 3			Timbale L												
67	G 3			Agogo H												
68	G# 3			Agogo L												
69	A 3			Cabasa									Rain	Laughing		
70	A# 3			Maracas					Analog Maracas				Thunder	Screaming		
71	B 3	O		Samba Whistle H									Wind	Punch		
72	C 4	O		Samba Whistle L									Stream	Heartbeat		
73	C# 4			Guiro Short									Bubble	Footsteps		
74	D 4	O		Guiro Long									Feed	Applaus2		
75	D# 4			Claves					Analog Claves							
76	E 4			Wood Block H												
77	F 4			Wood Block L												
78	F# 4			Cuica Mute				Scratch Push	Scratch Push							
79	G 4			Cuica Open				Scratch Pull	Scratch Pull							
80	G# 4		2	Triangle Mute												
81	A 4		2	Triangle Open												
82	A# 4			Shaker												
83	B 4			Jingle Bell												
84	C 5			Bell Tree												
85	C# 5												Dog	Machine Gun		
86	D 5												Horse Gallop	Laser Gun		
87	D# 5												Bird 2	Explosion		
88	E 5												Kitty	FireWork		
89	F 5												Growl			
90	F# 5												Haunted			
91	G 5												Gorst			
													Maou			

： Standard Kit と同じ

： 音はありません

# TG300-B Drum Map (ドラムボイス)

Program #			1	9	17	25	26	33	41	49	57	128
Note#	Note	Alternate assign	Standard Kit	Room Kit	Power Kit	Electro Kit	Analog Kit	Jazz Kit	Brush Kit	Orchestra Kit	SFX Set	C/M Kit
25	C# 0		Snare Roll									
26	D 0		Finger Snap									
27	D# 0		Hi Q							Hi-Hat Closed		
28	E 0		Whip Slap							Hi-Hat Pedal		
29	F 0	7	Scratch Push							Hi-Hat Open		
30	F# 0	7	Scratch Pull							Ride Cymbal 1		
31	G 0		Sticks									
32	G# 0		Click Noise									
33	A 0		Metronome Click									
34	A# 0		Metronome Bell									
35	B 0		Bass Drum M							BD Jazz		
36	C 1		Bass Drum H	BD Room	BD Power	BD Electronic	BD Analog H	BD Jazz	BD Soft	Gran Cassa		
37	C# 1		Side Stick				Analog Side Stick					
38	D 1		Snare M		SD Power	SD Electronic	Analog Snare L		Brush Tap	Concert SD		
39	D# 1		Hand Clap						Brush Slap	Castanet	High-Q	
40	E 1		Snare H			SD Power			Brush Swirl	Concert SD	Slap	SD Electro
41	F 1		Floor Tom L	Room Tom 1	Room Tom 1	E Tom 1	Analog Tom 1	Jazz Tom 1	Jazz Tom 1	Timpani F	Scratch Push	
42	F# 1	1	Hi-Hat Closed				Analog HH Closed 1			Timpani F#	Scratch Pull	
43	G 1		Floor Tom H	Room Tom 2	Room Tom 2	E Tom 2	Analog Tom 2	Jazz Tom 2	Jazz Tom 2	Timpani G	Sticks	
44	G# 1	1	Hi-Hat Pedal				Analog HH Closed 2			Timpani G#	Square Click	Hi-Hat Open 1
45	A 1		Low Tom	Room Tom 3	Room Tom 3	E Tom 3	Analog Tom 3	Jazz Tom 3	Jazz Tom 3	Timpani A	Metronome Click	
46	A# 1	1	Hi-Hat Open				Analog HH Open			Timpani A#	Metronome Bell	Hi-Hat Open 2
47	B 1		Mid Tom L	Room Tom 4	Room Tom 4	E Tom 4	Analog Tom 4	Jazz Tom 4	Jazz Tom 4	Timpani B	Guitar Fret Noise	
48	C 2		Mid Tom H	Room Tom 5	Room Tom 5	E Tom 5	Analog Tom 5	Jazz Tom 5	Jazz Tom 5	Timpani C	Guitar Cutting Down	
49	C# 2		Crash Cymbal 1				Analog Cymbal			Timpani C#	Guitar Cutting Up	
50	D 2		High Tom	Room Tom 6	Room Tom 6	E Tom 6	Analog Tom 6	Jazz Tom 6	Jazz Tom 6	Timpani D	Ac Bass Slap	
51	D# 2		Ride Cymbal 1							Timpani D#	FL Key Click	
52	E 2		Chinese Cymbal			Reverse Cymbal				Timpani E	Laughing	
53	F 2		Ride Cymbal Cup							Timpani F	Screaming	
54	F# 2		Tambourine								Punch	
55	G 2		Splash Cymbal								Heartbeat	
56	G# 2		Cowbell				Analog Cowbell				Footsteps 1	
57	A 2		Crash Cymbal 2							Hand Cym.1	Footsteps 2	
58	A# 2		Vibraslap								Applause	
59	B 2		Ride Cymbal 2							Hand Cym.2	Door Creaking	
60	C 3		Bongo H								Door Slam	
61	C# 3		Bongo L								Scratch	
62	D 3		Conga H Mute				Analog Conga H				Windchime	
63	D# 3		Conga H Open				Analog Conga M				Engine Start	
64	E 3		Conga L				Analog Conga L				Tire Screech	
65	F 3		Timbale H								Car Passing	
66	F# 3		Timbale L								Crash	
67	G 3		Agogo H								Siren	
68	G# 3		Agogo L								Train	
69	A 3		Cabasa								Jetplane	
70	A# 3		Maracas				Analog Maracas				Helicopter	
71	B 3	2	Samba Whistle H								Starship	
72	C 4	2	Samba Whistle L								Gunshot	
73	C# 4	3	Guiro Short								Machine Gun	Vibraslap
74	D 4	3	Guiro Long								Laser Gun	
75	D# 4		Claves				Analog Claves				Explosion	
76	E 4		Wood Block H								Dog	Laughing
77	F 4		Wood Block L								Horse Gallop	Screaming
78	F# 4	4	Cuica Mute								Bird Tweet	Punch
79	G 4	4	Cuica Open								Rain	Heartbeat
80	G# 4	5	Triangle Mute								Thunder	Footsteps 1
81	A 4	5	Triangle Open								Wind	Footsteps 2
82	A# 4		Shaker								Seashore	Applause
83	B 4		Jingle Bell								Stream	Door Creaking
84	C 5		Bell Tree								Bubble	Door Slam
85	C# 5		Castanet									Scratch
86	D 5	6	Surdo Mute									Windchime
87	D# 5	6	Surdo Open									Engine Start
88	E 5									Applause		Tire Screech
89	F 5											Car Passing
90	F# 5											Crash
91	G 5											Siren
92	G# 5											Train
93	A 5											Jetplain
94	A# 5											Helicopter
95	B 5											Starship
96	C 6											Gunshot
97	C# 6											Machine Gun
98	D 6											Laser Gun
99	D# 6											Explosion
100	E 6											Dog
101	F 6											Horse Gallop
102	F# 6											Bird Tweet
103	G 6											Rain
104	G# 6											Thunder
105	A 6											Wind
106	A# 6											Seashore
107	B 6											Stream
108	C 7											Bubble

Standard Kit と同じ

音はなりません

# C/M Drum Map (ドラムボイス)

Note#	Note	Alternate Assign	C/M Kit
35	B0		Bass Drum M
36	C1		Bass Drum H
37	C#1		Side Stick
38	D1		Snare M
39	D#1		Hand Clap
40	E1		SD Electro
41	F1		Floor Tom L
42	F#1	1	Hi-Hat Closed
43	G1		Floor Tom H
44	G#1	1	Hi-Hat Open 1
45	A1		Low Tom
46	A#1	1	Hi-Hat Open 2
47	B1		Mid Tom L
48	C2		Mid Tom H
49	C#2		Crash Cymbal 1
50	D2		High Tom
51	D#2		Ride Cymbal 1
52	E2		
53	F2		
54	F#2		Tambourine
55	G2		
56	G#2		Cowbell
57	A2		
58	A#2		
59	B2		
60	C3		Bongo H
61	C#3		Bongo L
62	D3		Conga H Mute
63	D#3		Conga H Open
64	E3		Conga L
65	F3		Timbale H
66	F#3		Timbale L
67	G3		Agogo H
68	G#3		Agogo L
69	A3		Cabasa
70	A#3		Maracas
71	B3	2	Samba Whistle H
72	C4	2	Samba Whistle L
73	C#4		Vibraslap
74	D4		
75	D#4		Claves
76	E4		Laughing
77	F4		Screaming
78	F#4		Punch
79	G4		Heartbeat
80	G#4		Footsteps 1
81	A4		Footsteps 2
82	A#4		Applause
83	B4		Door Creaking
84	C5		Door Slam
85	C#5		Scratch
86	D5		Windchime
87	D#5		Engine Start
88	E5		Tire Screech
89	F5		Car Passing
90	F#5		Crash
91	G5		Siren
92	G#5		Train
93	A5		Jetplane
94	A#5		Helicopter
95	B5		Starship
96	C6		Gunshot
97	C#6		Machine Gun
98	D6		Laser Gun
99	D#6		Explosion
100	E6		Dog
101	F6		Horse Gallop
102	F#6		Bird Tweet
103	G6		Rain
104	G#6		Thunder
105	A6		Wind
106	A#6		Seashore
107	B6		Stream
108	C7		Bubble

■ : 音はなりません



# ヤマハ株式会社