

【資料】楽器別互換表

Drum Kit SFX Kit	Standard Kit 1 Live!Std Kit Live!Std+P Kit	互換範囲	Standard Kit 2 Live!Funk Kit Live!Funk+P Kit	互換範囲	HitKit	互換範囲	RoomKit	互換範囲	RockKit	互換範囲	ElectroKit	互換範囲	AnalogKit	互換範囲	DanceKit	互換範囲	JazzKit	互換範囲	BrushKit Live!Brush Kit Live!Bruf+P Kit	互換範囲	SymphonyKit	互換範囲	
13	C#-1	Surdo Mute	30	Surdo Mute	30	Surdo Mute	30	Surdo Mute	30	Surdo Mute	30	Surdo Mute	30	Surdo Mute	30	Kick Dance 1	19	Surdo Mute	30	Surdo Mute	30	Surdo Mute	30
14	D-1	Surdo Open	35	Surdo Open	35	Surdo Open	35	Surdo Open	35	Surdo Open	35	Surdo Open	35	Surdo Open	35	Kick Dance 2	19	Surdo Open	35	Surdo Open	35	Surdo Open	35
15	D#-1	Hi Q	21	Hi Q	21	Hi Q	21	Hi Q	21	Hi Q	21	Hi Q	21	Hi Q	21	Hi Q	21	Hi Q	21	Hi Q	21	Hi Q	21
16	E-1	Whip Slap	24	Whip Slap	24	Whip Slap	24	Whip Slap	24	Whip Slap	24	Whip Slap	24	Whip Slap	24	Whip Slap	19	Whip Slap	24	Whip Slap	24	Whip Slap	24
17	F-1	Scratch H	24	Scratch H	24	Scratch H	24	Scratch H	24	Scratch H	24	Scratch H	24	Scratch H	24	Scratch Dance 1	19	Scratch H	24	Scratch H	24	Scratch H	24
18	F#-1	Scratch L	24	Scratch L	24	Scratch L	24	Scratch L	24	Scratch L	24	Scratch L	24	Scratch L	24	Scratch Dance 2	19	Scratch L	24	Scratch L	24	Scratch L	24
19	G-1	Finger Snap	16	Finger Snap	16	Finger Snap	16	Finger Snap	16	Finger Snap	16	Finger Snap	16	Finger Snap	16	Finger Snap	16	Finger Snap	16	Finger Snap	16	Finger Snap	16
20	G#-1	Click Noise	16	Click Noise	16	Click Noise	16	Click Noise	16	Click Noise	16	Click Noise	16	Click Noise	16	Click Noise	16	Click Noise	16	Click Noise	16	Click Noise	16
21	A-1	Metronome Click	25	Metronome Click	25	Metronome Click	25	Metronome Click	25	Metronome Click	25	Metronome Click	25	Metronome Click	25	Dance Perc 1	19	Metronome Click	25	Metronome Click	25	Metronome Click	25
22	A#-1	Metronome Bell	18	Metronome Bell	18	Metronome Bell	18	Metronome Bell	18	Metronome Bell	18	Metronome Bell	18	Metronome Bell	18	Reverse Dance 1	19	Metronome Bell	18	Metronome Bell	18	Metronome Bell	18
23	B-1	Seq Click L	12	Seq Click L	12	Seq Click L	12	Seq Click L	12	Seq Click L	12	Seq Click L	12	Seq Click L	12	Dance Perc 2	19	Seq Click L	12	Seq Click L	12	Seq Click L	12
24	C0	Seq Click H	12	Seq Click H	12	Seq Click H	12	Seq Click H	12	Seq Click H	12	Seq Click H	12	Seq Click H	12	Hi Q Dance 1	19	Seq Click H	12	Seq Click H	12	Seq Click H	12
25	C#0	Brush Tap	24	Brush Tap	24	Brush Tap	24	Brush Tap	24	Brush Tap	24	Brush Tap	24	Brush Tap	24	Snare Analog 3	19	Brush Tap	24	Brush Tap	24	Brush Tap	24
26	D0	Brush Swirl	12	Brush Swirl	12	Brush Swirl	12	Brush Swirl	12	Brush Swirl	12	Brush Swirl	12	Brush Swirl	12	Vinyl Noise	34	Brush Swirl	12	Brush Swirl	12	Brush Swirl	12
27	D#0	Brush Slap	24	Brush Slap	24	Brush Slap	24	Brush Slap	24	Brush Slap	24	Brush Slap	24	Brush Slap	24	Snare Analog 4	19	Brush Slap	24	Brush Slap	24	Brush Slap	24
28	E0	Brush Tap Swirl	12	Brush Tap Swirl	12	Brush Tap Swirl	12	Brush Tap Swirl	12	Brush Tap Swirl	12	Reverse Cymbal	21	Reverse Cymbal	21	Reverse Cymbal	21	Brush Tap Swirl	12	Brush Tap Swirl	12	Brush Tap Swirl	12
29	F0	Snare Roll	19	Snare Roll	19	Snare Roll	19	Snare Roll	19	Snare Roll	19	Snare Roll	19	Snare Roll	19	Reverse Dance 2	19	Snare Roll	19	Snare Roll	19	Snare Roll	19
30	F#0	Castanet	30	Castanet	30	Castanet	30	Castanet	30	Castanet	30	Hi Q 2	28	Hi Q 2	28	Hi Q 2	19	Castanet	30	Castanet	30	Castanet	30
31	G0	Snare Soft	24	Snare Soft 2	24	Snare Electro	18	Snare Soft	24	Snare Noisy	25	Snare Snap Elec	21	Snare Noisy 4	24	Snare Techno	19	Snare Jazz H	29	Brush Slap 2	24	Snare Soft	24
32	G#0	Sticks	22	Sticks	22	Sticks	22	Sticks	22	Sticks	22	Sticks	22	Sticks	22	Snare Dance 1	19	Sticks	22	Sticks	22	Sticks	22
33	A0	Kick Soft	19	Kick Soft	19	Kick Tight L	19	Kick Soft	19	Kick Soft	19	Kick 3	25	Kick 3	25	Kick Techno Q	19	Kick Soft	19	Kick Soft	19	Kick Soft 2	19
34	A#0	Open Rim Shot	24	Open Rim Shot H	24	Snare Pitched	19	Open Rim Shot	24	Open Rim Shot	24	Open Rim Shot	24	Open Rim Shot	24	Rim Gate	19	Open Rim Shot	24	Open Rim Shot	24	Open Rim Shot	24
35	B0	Kick Tight	19	Kick Tight	19	Kick Wet	19	Kick Tight	19	Kick 2	25	Kick Gate	30	Kick Anlg Short	44	Kick Techno L	19	Kick Tight	19	Kick Tight	19	Gran Cassa	31
36	C1	Kick	24	Kick Short	19	Kick Tight H	17	Kick	24	Kick Gate	30	Kick Gate Heavy	28	Kick Analog	41	Kick Techno	19	Kick Jazz	36	Kick Jazz	19	Gran Cassa Mute	31
37	C#1	Side Stick	24	Side Stick Light	24	Stick Ambient	19	Side Stick	24	Side Stick	24	Side Stick	24	Side Stick Anlg	24	Side Stick Anlg	19	Side Stick Light	25	Side Stick Light	24	Side Stick	24
38	D1	Snare	24	Snare Short	24	Snare Ambient	19	Snare Snappy	21	Snare Rock	26	Snare Noisy 2	25	Snare Analog	27	Snare Clap	19	Snare Jazz L	32	Brush Slap 3	24	Band Snare	19
39	D#1	Hand Clap	24	Hand Clap	24	Hand Clap	24	Hand Clap	24	Hand Clap	24	Hand Clap	24	Hand Clap	24	Dance Clap	19	Hand Clap	24	Hand Clap	24	Hand Clap	24
40	E1	Snare Tight	24	Snare Tight H	24	Snare Tight 2	20	Snare Tight Snap	21	Snare Rock Tight	21	Snare Noisy 3	24	Snare Analog 2	34	Snare Dry	19	Snare Jazz M	29	Brush Tap 2	24	Band Snare 2	19
41	F1	Floor Tom L	24	Floor Tom L	24	Hybrid Tom 1	26	Tom Room 1	41	Tom Rock 1	40	Tom Electro 1	34	Tom Analog 1	48	Tom Dance 1	24	Floor Tom L	24	Tom Brush 1	27	Floor Tom L	24
42	F#1	Hi-Hat Closed	6	Hi-Hat Closed	6	Hi-Hat Closed 2	6	Hi-Hat Closed	6	Hi-Hat Closed	6	Hi-Hat Closed	6	Hat Close Analog	14	Hi-Hat Closed 3	19	Hi-Hat Closed	6	Hi-Hat Closed	6	Hi-Hat Closed	6
43	G1	Floor Tom H	24	Floor Tom H	24	Hybrid Tom 2	24	Tom Room 2	39	Tom Rock 2	38	Tom Electro 2	30	Tom Analog 2	45	Tom Dance 2	24	Floor Tom H	24	Tom Brush 2	24	Floor Tom H	24
44	G#1	Hi-Hat Pedal	6	Hi-Hat Pedal	6	Hi-Hat Pedal 2	6	Hi-Hat Pedal	6	Hi-Hat Pedal	6	Hi-Hat Pedal	6	Hat Close Anlg 2	10	Hat Close Anlg 3	14	Hi-Hat Pedal	6	Hi-Hat Pedal	6	Hi-Hat Pedal	6
45	A1	Low Tom	21	Low Tom	21	Hybrid Tom 3	24	Tom Room 3	37	Tom Rock 3	36	Tom Electro 3	28	Tom Analog 3	41	Tom Dance 3	21	Low Tom	21	Tom Brush 3	21	Low Tom	21
46	A#1	Hi-Hat Open	6	Hi-Hat Open	6	Hi-Hat Open 2	6	Hi-Hat Open	6	Hi-Hat Open	6	Hi-Hat Open	6	Hat Open Analog	3	Hi-Hat Open 3	16	Hi-Hat Open	6	Hi-Hat Open	6	Hi-Hat Open	6
47	B1	Mid Tom L	24	Mid Tom L	24	Hybrid Tom 4	24	Tom Room 4	36	Tom Rock 4	35	Tom Electro 4	24	Tom Analog 4	36	Tom Dance 4	24	Mid Tom L	24	Tom Brush 4	27	Mid Tom L	24
48	C2	Mid Tom H	21	Mid Tom H	21	Hybrid Tom 5	26	Tom Room 5	34	Tom Rock 5	33	Tom Electro 5	20	Tom Analog 5	32	Tom Dance 5	21	Mid Tom H	21	Tom Brush 5	24	Mid Tom H	21
49	C#2	Crash Cymbal 1	15	Crash Cymbal 1	15	Crash Cymbal 1	15	Crash Cymbal 1	15	Crash Cymbal 1	15	Crash Cymbal 1	15	Crash Analog	19	Crash Analog	19	Crash Cymbal 1	15	Crash Cymbal 1	15	Hand Cymbal	11
50	D2	High Tom	24	High Tom	24	Hybrid Tom 6	24	Tom Room 6	32	Tom Rock 6	31	Tom Electro 6	16	Tom Analog 6	28	Tom Dance 6	24	High Tom	24	Tom Brush 6	27	High Tom	24
51	D#2	Ride Cymbal 1	13	Ride Cymbal 1	13	Ride Cymbal 1	13	Ride Cymbal 1	13	Ride Cymbal 1	13	Ride Cymbal 1	13	Ride Cymbal 1	13	Ride Cymbal 1	13	Ride Cymbal 1	13	Ride Cymbal 1	13	Hand Cymbal S	11
52	E2	Chinese Cymbal	15	Chinese Cymbal	15	Chinese Cymbal	15	Chinese Cymbal	15	Chinese Cymbal	15	Chinese Cymbal	15	Chinese Cymbal	15	Chinese Cymbal	15	Chinese Cymbal	15	Chinese Cymbal	15	Chinese Cymbal	15
53	F2	Ride Cymbal Cup	16	Ride Cymbal Cup	16	Ride Cymbal Cup	16	Ride Cymbal Cup	16	Ride Cymbal Cup	16	Ride Cymbal Cup	16	Ride Cymbal Cup	16	Ride Cymbal Cup	16	Ride Cymbal Cup	16	Ride Cymbal Cup	16	Ride Cymbal Cup	16
54	F#2	Tambourine	4	Tambourine	4	Tambourine Light	4	Tambourine	4	Tambourine	4	Tambourine	4	Tambourine	4	Tambourine Anlg	8	Tambourine	4	Tambourine	4	Tambourine	4
55	G2	Splash Cymbal	7	Splash Cymbal	7	Splash Cymbal	7	Splash Cymbal	7	Splash Cymbal	7	Splash Cymbal	7	Splash Cymbal	7	Splash Cymbal	7	Splash Cymbal	7	Splash Cymbal	7	Splash Cymbal	7
56	G#2	Cowbell	20	Cowbell	20	Cowbell	20	Cowbell	20	Cowbell	20	Cowbell	20	Cowbell Analog	27	Cowbell Dance	19	Cowbell	20	Cowbell	20	Cowbell	20
57	A2	Crash Cymbal 2	14	Crash Cymbal 2	14	Crash Cymbal 2	14	Crash Cymbal 2	14	Crash Cymbal 2	14	Crash Cymbal 2	14	Crash Cymbal 2	14	Crash Cymbal 2	14	Crash Cymbal 2	14	Crash Cymbal 2	14	Hand Cymbal 2	10
58	A#2	Vibraslap	19	Vibraslap	19	Vibraslap	19	Vibraslap	19	Vibraslap	19	Vibraslap	19	Vibraslap	19	Vibraslap Analog	29	Vibraslap	19	Vibraslap	19	Vibraslap	19
59	B2	Ride Cymbal 2	13	Ride Cymbal 2	13	Ride Cymbal 2	13	Ride Cymbal 2	13	Ride Cymbal 2	13	Ride Cymbal 2	13	Ride Cymbal 2	13	Ride Analog	12	Ride Cymbal 2	13	Ride Cymbal 2	13	Hand Cymbal 2 S	12
60	C3	Bongo H	24	Bongo H	24	Bongo H	24	Bongo H	24	Bongo H	24	Bongo H	24	Bongo H	24	Bongo Analog H	19	Bongo H	24	Bongo H	24	Bongo H	24
61	C#3	Bongo L	24	Bongo L	24	Bongo L	24	Bongo L	24	Bongo L	24	Bongo L	24	Bongo L	24	Bongo Analog L	19	Bongo L	24	Bongo L	24	Bongo L	24
62	D3	Conga H Mute	24	Conga H Mute	24	Conga H Mute	24	Conga H Mute	24	Conga H Mute	24	Conga H Mute	24	Conga Analog H	20	Conga Analog H	20	Conga H Mute	24	Conga H Mute	24	Conga H Mute	24
63	D#3	Conga H Open	27	Conga H Open	27	Conga H Open	27	Conga H Open	27	Conga H Open	27	Conga H Open	27	Conga Analog M	27	Conga Analog M	27	Conga H Open	27	Conga H Open	27	Conga H Open	27
64	E3	Conga L	24	Conga L	24	Conga L	24	Conga L	24	Conga L	24	Conga L	24	Conga Analog L	33	Conga Analog L	33	Conga L	24	Conga L	24	Conga L	24
65	F3	Timbale H	27	Timbale H	27	Timbale H	27	Timbale H	27	Timbale H	27	Timbale H	27	Timbale H	27	Timbale H	27	Timbale H	27	Timbale H	27	Timbale H	27
66	F#3	Timbale L	27	Timbale L	27	Timbale L	27	Timbale L	27	Timbale L	27	Timbale L	27	Timbale L	27	Timbale L	27	Timbale L	27	Timbale L	27	Timbale L	27
67	G3	Agogo H	24	Agogo H	24	Agogo H	24	Agogo H	24	Agogo H	24	Agogo H	24	Agogo H	24	Agogo H	24	Agogo H	24	Agogo H	24	Agogo H	24
68	G#3	Agogo L	26	Agogo L	26	Agogo L	26	Agogo L	26	Agogo L	26	Agogo L	26	Agogo L	26	Agogo L	26	Agogo L	26	Agogo L	26	Agogo L	26
69	A3	Cabasa	6	Cabasa	6	Cabasa	6	Cabasa	6	Cabasa	6	Cabasa	6	Cabasa	6	Cabasa	6	Cabasa	6	Cabasa	6	Cabasa	6
70	A#3	Maracas	7	Maracas	7	Maracas	7	Maracas	7	Maracas	7	Maracas	7	Maracas 2	21	Maracas 2	21	Maracas	7	Maracas	7	Maracas	7
71	B3	Samba Whistle H	17	Samba Whistle H	17	Samba Whistle H	17	Samba Whistle H	17	Samba Whistle H	17	Samba Whistle H	17	Samba Whistle H	17	Samba Whistle H	17	Samba Whistle H	17	Samba Whistle H	17	Samba Whistle H	17
72	C4	Samba Whistle L	18	Samba Whistle L	18	Samba Whistle L	18	Samba Whistle L	18	Samba Whistle L	18	Samba Whistle L	18	Samba Whistle L	18	Samba Whistle L	18	Samba Whistle L	18	Samba Whistle L	18	Samba Whistle L	18
73	C#4	Guiro Short	19	Guiro Short	19	Guiro Short	19	Guiro Short	19	Guiro Short	19	Guiro Short	19	Guiro Short	19	Guiro Short	19	Guiro Short	19	Guiro Short	19	Guiro Short	19
74	D4	Guiro Long	19	Guiro Long	19	Guiro Long	19	Guiro Long	19	Guiro Long	19	Guiro Long	19	Guiro Long	19	Guiro Long	19	Guiro Long	19	Guiro Long	19	Guiro Long	19
75	D#4	Claves	31	Claves	31	Claves	31	Claves	31	Claves	31	Claves	31	Claves 2	30	Claves 2	30	Claves	31	Claves	31	Claves	31
76	E4	Wood Block H	33	Wood Block H	33	Wood Block H	33	Wood Block H	33	Wood Block H	33	Wood Block H	33	Wood Block H	33	Dance Perc 3	19	Wood Block H	33	Wood Block H	33	Wood Block H	33
77	F4	Wood Block L	39	Wood Block L	39	Wood Block L	39	Wood Block L	39														

【資料】楽器別

Drum Kit SFX Kit	Live! StudioKit	互換 範囲	SFXKit1	互換 範囲	SFXKit2	互換 範囲	ArabicKit	互換 範囲	Live! CubanKit	互換 範囲	Live! PopLatinKit	互換 範囲	
13	C#-1	Surdo Mute	30	no sound	no sound		no sound		no sound		no sound		
14	D-1	Surdo Open	35										
15	D#-1	Hi Q	21										
16	E-1	Whip Slap	24										
17	F-1	Scratch H	24										
18	F#-1	Scratch L	24								Hand Clap	24	
19	G-1	Finger Snap	16										
20	G#-1	Click Noise	16										
21	A-1	Metronome Click	25										
22	A#-1	Metronome Bell	18						Conga H Tip	24	Conga H Tip	24	
23	B-1	Seq Click L	12						Conga H Heel	24	Conga H Heel	24	
24	C0	Seq Click H	12	no sound	no sound		Nakarazan Dom	34	Conga H Open	27	Conga H Open	27	
25	C#0	Brush Tap	24				Cabasa	15	Conga H Mute	27	Conga H Mute	27	
26	D0	Brush Swirl	12				Nakarazan Edge	39	Conga H SlapOpen	24	Conga H SlapOpen	24	
27	D#0	Brush Slap	24				Hager Dom	39	Conga H Slap	24	Conga H Slap	24	
28	E0	Brush Tap Swirl	12				Hager Edge	36	Conga H SlapMute	24	Conga H SlapMute	24	
29	F0	Snare Roll	19				Bongo H	37	Conga L Tip	24	Conga L Tip	24	
30	F#0	Castanet	30				Bongo L	37	Conga L Heel	24	Conga L Heel	24	
31	G0	Snare Studio L	27				Conga H Mute	17	Conga L Open	24	Conga L Open	24	
32	G#0	Sticks	22				Conga H Open	24	Conga L Mute	27	Conga L Mute	27	
33	A0	Kick Ambience H	28				Conga L	24	Conga L SlapOpen	24	Conga L SlapOpen	24	
34	A#0	Open Rim Shot	24				Zagrouda H	23	Conga L Slap	27	Conga L Slap	27	
35	B0	Kick Ambience L	23				Zagrouda L	32	Conga L Slide	24	Conga L Slide	24	
36	C1	Kick Studio	22	Cutting Noise 1	26	Phone Call	45	Kick Soft	30	Bongo H Open 1 f	24	Bongo H Open 1 f	24
37	C#1	Side Stick	24	Cutting Noise 2	20	Door Squeak	34	Side Stick	24	Bongo H Open 3 f	27	Bongo H Open 3 f	27
38	D1	Snare Studio M	27	no sound		Door Slam	39	Snare Soft	19	Bongo H Rim	27	Bongo H Rim	27
39	D#1	Hand Clap	24	String Slap	31	Scratch Cut	33	Arabic Hand Clap	24	Bongo H Tip	27	Bongo H Tip	27
40	E1	Snare Studio L	22	no sound		Scratch H 3	24	Snare Drum	24	Bongo H Heel	27	Bongo H Heel	27
41	F1	Floor Tom L	24			Wind Chime	18	Floor Tom L	30	Bongo H Slap	27	Bongo H Slap	27
42	F#1	Hi-Hat Closed	6			Telephone Ring	30	Hi-Hat Closed	6	Bongo L Open 1 f	24	Bongo L Open 1 f	24
43	G1	Floor Tom H	24					Floor Tom H	31	Bongo L Open 3 f	27	Bongo L Open 3 f	27
44	G#1	Hi-Hat Pedal	6					Hi-Hat Pedal	6	Bongo L Rim	27	Bongo L Rim	27
45	A1	Low Tom	21					Low Tom	28	Bongo L Tip	27	Bongo L Tip	27
46	A#1	Hi-Hat Open	6					Hi-Hat Open	6	Bongo L Heel	27	Bongo L Heel	27
47	B1	Mid Tom L	24					Mid Tom L	32	Bongo L Slap	27	Bongo L Slap	27
48	C2	Mid Tom H	21	no sound	no sound			Mid Tom H	29	Timble L Open	27	Timble L Open	27
49	C#2	Crash Cymbal 1	15					Crash Cymbal 1	14	no sound		no sound	
50	D2	High Tom	24					High Tom	31				
51	D#2	Ride Cymbal 1	13					Ride Cymbal 1	15				
52	E2	Chinese Cymbal	15	Flute Key Click	33	CarEngn Ignition	32	Crash Cymbal 2	14				
53	F2	Ride Cymbal Cup	16	no sound		Car Tires Squeal	34	Duhulla Dom	24	Paila L	13	Paila L	13
54	F#2	Tambourine	4			Car Passing	34	Tambourine	4	Timbale H Open	27	Timbale H Open	27
55	G2	Splash Cymbal	7			Car Crash	35	Duhulla Tak	24				
56	G#2	Cowbell	20			Siren	10	Cowbell	20				
57	A2	Crash Cymbal 2	14			Train	40	Duhulla Sak	24				
58	A#2	Vibraslap	19			Jet Plane	24	Claves	31				
59	B2	Ride Cymbal 2	13			Starship	4	Doff Dom	24	Paila H	13	Paila H	13
60	C3	Bongo H	24	no sound		Burst	6	Katemb Dom	24	Cowbell Top	20	Cowbell Top	20
61	C#3	Bongo L	24			Roller Coaster	20	Katemb Tak	32	no sound		no sound	
62	D3	Conga H Mute	24			Submarine	63	Katemb Sak	32				
63	D#3	Conga H Open	27			no sound		Katemb Tak	32				
64	E3	Conga L	24					Doff Tak	36	Guiro Short	20	Guiro Short	20
65	F3	Timbale H	27					Tabla Dom	24	Guiro Long	20	Guiro Long	20
66	F#3	Timbale L	27					Tabla Tak 1	24				
67	G3	Agogo H	24					Tabla Tik	34				
68	G#3	Agogo L	26	Shower	24	Laugh	34	Tabla Tak 2	24	Tambourine	4	Tambourine	4
69	A3	Cabasa	6	Thunder	41	Scream	30	Tabla Sak	24				
70	A#3	Maracas	7	Wind	37	Punch	34	Tabla Roll Edge	24				
71	B3	Samba Whistle H	17	Stream	29	Heart Beat	36	Tabla Flam	32				
72	C4	Samba Whistle L	18	Bubble	46	Foot Steps	33	Sagat 1	6	Maracas	6	Maracas	6
73	C#4	Guiro Short	19	Feed	63	no sound		Tabel Dom	32	Shaker	6	Shaker	6
74	D4	Guiro Long	19	no sound				Sagat 3	6	Cabasa	6	Cabasa	6
75	D#4	Claves	31					Tabel Tak	39	no sound		Cuica Mute	22
76	E4	Wood Block H	33					Sagat 2	6			Cuica Open	19
77	F4	Wood Block L	39					Rik Dom	36			no sound	
78	F#4	Cuica Mute	19					Rik Tak 2	36				
79	G4	Cuica Open	22					Rik Finger 1	34				
80	G#4	Triangle Mute	5					Rik Tak 1	22				
81	A4	Triangle Open	3					Rik Finger 2	34			Triangle Mute	4
82	A#4	Shaker	6					Rik BrassTremolo	19			Triangle Open	4
83	B4	Jingle Bells	14					Rik Sak	36				
84	C5	Bell Tree	2	Dog	33	Machine Gun	21	Rik Tik	34	no sound		Wind Chime	2
85	C#5	no sound		Horse	33	Laser Gun	19	no sound				no sound	
86	D5			Bird Tweet	30	Explosion	44						
87	D#5			no sound		Firework	39						
88	E5					no sound							
89	F5												
90	F#5			Ghost	28								
91	G5			Maou	56								

ドラムピッチコースの値が、資料の“互換範囲”とされている数値以下に設定されていれば、ELS-01とELS-02のデータ互換性を保つことができます。

【資料】楽器別互換表

Drum Kit SFX Kit	Standard Kit 1 Live!Std Kit Live!Std+P Kit	互換 範囲	
13	C#-1	Surdo Mute	30
14	D-1	Surdo Open	35
15	D#-1	Hi Q	21
16	E-1	Whip Slap	24
17	F-1	Scratch H	24
18	F#-1	Scratch L	24

(資料の読み方)

Standard Kit 1のSuro Muteは、ピッチコース値が“+30”以下であれば、互換性を保つことができます。