

HAUPTWERK C-c⁴

Bordun	32'
Praestant	16'
Rohrbordun	16'
Principal	8'
Flûte harmonique	8'
Bordun	8'
Salicional	8'
Octave	4'
Rohrflöte	4'
Quinte	2 2/3'
Waldflöte	2'
Superoctave	2'
Cornett V	
Mixtur IV-VI	
Cymbel III	
Trompete	16'
Trompete	8'

POSITIV (Swellbar) C-c⁴

Salicional	16'
Geigenprincipal	8'
Suavial	8'
Unda maris	8'
Gedackt	8'
Aeoline	8'
Fugara	4'
Querflöte	4'
Kornett II-III	
Flautino	2'
Piccolo	1'
Harmonia aetheria III	
Scharff IV	
Fagott	16'
Dulcian	8'
Vox humana	8'
Glockenspiel d-g ²	
Tremulant	

III SCHWELLWERK C-c⁴

Lieblich Gedackt	16'
Diapason	8'
Gambe	8'
Vox coelestis	8'
Rohrflöte	8'
Principal	4'
Viola	4'
Nasard	2 2/3'
Flageolett	2'
Doublette	2'
Terz	1 3/5'
Fourniture V	
Basson	16'
Trompette harmonique	8'
Oboe	8'
Clairon	8'
Tremulant	

PEDAL C-g¹

Untersatz	32'
Principalbaß	16'
Subbaß	16'
Kontrabaß	16'
Lieblich Gedackt	16'
Baßaliquot III	
Octavbaß	8'
Baßflöte	8'
Cello	8'
Octave	4'
Gemshorn	4'
Nachthorn	2'
Mixtur V	
Bombarde	32'
Posaune	16'
Basson	16'
Trompete	8'

IV CHAMADENWERK C-c⁴

Trompete en chamade	16'
Trompete en chamade	8'
Trompete en chamade	4'
Klarinette	8'

Mechanische Koppeln: - , - , -P, -P, -P
 Elektrische Koppeln : - , - , - , - , - , - , -
 -P, P-
 Super (4') - , - , -P

(- , - は機械式 / 電気式切り替え可)

Mechanical key action : , , and Ped.

Electric key action :

Electric stop action

YAMAHA memory system

500 combinations

自動演奏装置(録音/再生)

メモリーカード